MARA-00479

Service Manual

74 SR50/60B/65B

Audio/Video stereo receiver

TABLE OF CONTENTS

SECTION	PAGE
1. BLOCK DIAGRAM	1
2. SCHEMATIC DIAGRAM AND PARTS LOCATION (Pattern side)	3
3. EXPLODED VIEW AND PARTS LIST	17
4. TEST EQUIPMENT REQUIRED FOR SERVICING	18
5. IDLING CURRENT ADJUSTMENT	19
6. VOLTAGE CONVERSION	19
7. HOW TO CHANGE THE SUPPLY VOLTAGE	19
8. SERVICE PROGRAM	20
9. TUNER ALIGMENT PROCEDURS	20
10. ALIGMENT AND TEST POINT	23
11. TUNER MICROPROCESSOR SPECIFICATIONS	23
12. ELECTRICAL PARTS LIST	26

marantz®

model SR-50L

First issue: 1990

4822 725 50917

MARANTZ DESIGN AND SERVICE

Using superior design and selected high grade components, MARANTZ company has created the ultimate in stereo sound.
Only **original MARANTZ parts** can insure that your MARANTZ product will continue to perform to the specifications for which it is famous.

Parts for your MARANTZ equipment are generally available to our National Marantz Subsidiary or Agent.

MARANTZ INTERNATIONAL
Vestdijk 9
5600 MD Eindhoven
The Netherlands
Phone: +31/40.758290
Telefax: +31/40.75.82.99
Telex: 35000 PHTC NL routing IND NLMTFAT

ORDERING PARTS:

Parts can be ordered either by mail or by telex. In both cases, correct part number has to be specified.
The following information must be supplied to eliminate delays in processing your order:

1. Complete address
2. Complete part numbers and quantities required
3. Description of parts
4. Model number for which part is required
5. Way of shipment
6. Signature: any order form or telex must be signed otherwise such part order will be considered as null and void.

PARTS ORDERING

Parts may be ordered at the following addresses:

AUSTRIA
HORNYPHON
Vertriebsgesellschaft GmbH
Wienerbergstrasse 1
A 1101 Wien
Austria
Telex: 132.332

BELGIUM
SVD DIVISION MARANTZ
Industrialaan 1
1720 Groot-Bijgaarden
Belgium
Telex: 24466

CHILE
MARANTZ
DIVISION OF PHILIPS S.A.
AV. Santa Maria, 0760
Casilla 2687
Santiago
Telex: 240.239

DENMARK
MARANTZ
DIVISION OF PHILIPS
SERVICE A/S
Prags Boulevard 80
Postbox 1919
DK-2300 København S
Denmark
Telex: 31201

FINLAND
MARANTZ
DIVISION OF OY PHILIPS Ab
Kaivokatu 8
00100 Helsinki
Finland
Telex: 124811

FRANCE
MARANTZ FRANCE
4 Rue Bernard Palissy
92600 Asnières
France
Telex: 611651

GERMANY
MARANTZ GERMANY GmbH
Alexanderstrasse 1
2000 Hamburg
Germany

THE NETHERLANDS
Elpro Marantz
Wint Hontlaan 28
3526 KV Utrecht
The Netherlands
Telex: 4748

NORWAY
MARANTZ
DIVISION OF PHILIPS A/S
Sandstuveien 40
0680 Oslo 6
Norway
Telex: 72640

GREAT BRITAIN
MARANTZ AUDIO U.K. Ltd
Unit 15/16
Saxon Way Industrial Estate
Moor Lane
Harmondsworth UB7 OLW
Great Britain
Telex: 935196

GREECE
SHERTON ELECTRONICS S.A.
P.O.Box 21025
Hippocratus Street 188
Athens 11471
Greece
Telex: 216.795

JAPAN
MARANTZ JAPAN, Inc.
35-1, 7-chome, Sagamiono
Sagamihara-shi, Kanagawa
Japan

KUWAIT
AL ALAMIAH ELECTRONICS
Ussama Building
Fahd al Saleem Street
P.O.Box 23781
Safat-Kuwait
Telex: 22694

ITALY
MARANTZ ITALIANA S.P.A.
Via Chiese, 74
20126 Milano
Italy

SAUDI ARABIA
AL ALAMIAH ELECTRONICS
P.O.Box 5954
University Street
Riyadh 11432
Saudi Arabia
Telex: 401530

SOUTH AFRICA
MARANTZ
DIVISION OF PHILIPS S.A.
Main Road Martindale
P.O. Box. 58088
Newville 21114
South Africa

SPAIN
PHONO S.A.
Ignacio Iglesias 10
Badalona (Barcelona)
Spain
Telex: 59355

SWEDEN
MARANTZ
DIVISION OF PHILIPS
Försäljning AB
Tegeluddsvägen 1
S-115 84 Stockholm
Sweden
Telex: 14060

SWITZERLAND
MARANTZ
Technischer Service
Duenstrasse 3
3186 Düdingen
Switzerland

TURKEY
DOGRUOL Ltd.
I.M.C.
6 Blok N°6310
Unkapani
Istanbul
Turkey
Telex: 22085

MALTA
CACHIA & GALEA
Republic Street, 68D
Valetta
Telex: 1682

PORTUGAL
MARANTZ
Divisao philips S.A. service
Outurela-carnaxide
2795 LinDA-A-VELHA
Telex: 43906

All of the above locations are fully equipped to take care of your total service needs. Because various countries have differing configuration requirements, it is necessary that you contact the service facility in your particular country. In the event that there is no service location listed for your country, please, contact the nearest facility for the necessary assistance.

In case of difficulties, do not hesitate to contact the Technical Department at abovementioned address.

TECHNICAL SPECIFICATIONS (DIN)

FM TUNER SECTION

Frequency range	87.5 – 108 MHz
Sensitivity DIN (Mono/Stereo)	1.0/25 μV
S/N (Mono/Stereo)	76/68 dB
T.H.D.	0.2/0.4%
Selectivity at 98 MHz (±300 kHz)	60 dB

MW TUNER SECTION

Frequency range	531 – 1602 kHz
Sensitivity (S/N 20 dB 30% 1 MHz)	500 μV
S/N at 1 MHz	50 dB

LW TUNER SECTION

Frequency range	152 – 282 kHz
Sensitivity (S/N 20 dB 30% 1 MHz)	1000 μV

AMPLIFIER SECTION

Power output	DIN 8Ω	50W
	RMS 8Ω	40W
T.H.D. at 8Ω rated RMS output		0.09%
Damping factor		50
Input sensitivity	: PHONO	3.5 mV/47 kΩ
	: CD/TV/CDV/VCR/TAPE	220 mV/47 kΩ
S/N (IHF-A)	: PHONO	76 dB
	: CD/TV/CDV/VCR/TAPE	86 dB

POWER SUPPLY	AC 220V, 50/60 Hz

DIMENSIONS

Width	420 mm
Height	118 mm
Depth	334 mm

WEIGHT	6.5 kg

SUPPLIED ACCESSORIES

Remote controller (RC-60SR) x 1
Batteries (Size "AAA", R03) x 2
FM dipole antenna x 1
AM loop antenna x 1

Specifications subject to change without prior notice.

1. BLOCK DIAGRAM





NOTE ON SAFETY:
Symbol ⚠ Fire or electrical shock hazard. Only original parts should be used to replace any part marked with symbol ⚠ . Any other component substitution (other than original type), may increase risk of fire or electrical shock hazard.

P104


QA03
QA01
QA02
Q201
Q202
J101
R102
R101
QA03
LA01
LA03
LA04
LA02
QA02
QA01
LA05
Q201
Q202
F201
F202
C201
C202
R201
R204
R205
R206
R207
R208
R301
C301
C203
C204
L201
C206
C207
C209
C205
R209
C208
C214
C215
C216
C217
C218
C219
C220
C221
C222
C223
C224
C225
C226
R211
R212
R213
R214
R215
R216
R217
R218
R219
R220
R221
R222
R223
R224
R225
R226
R227
R228
R229
R230
R231
R232
R233
R234
R235
R236
R237
R238
R239
R240
R241
R242
R243
R244
R245
R246
R247
R248
R249
R250

PU04 μ-COM, TACT SW. AND FL.





PU04


QU09
QU06
QU07
QU02
QU08
QU05
QU10
QU03
QU04
QU01
FR-70 ONLY
FR-50,FR-60
SR-50L,SR-60L
ONLY
FR-50,FR-60
FR-70 ONLY
FR-50(U),SR-50L ONLY
FR-60,FR-70,SR-60L
ONLY
SR-50L,SR-60L
ONLY
FR-70
FR-60
SR-60L
ONLY
FR-60 ONLY
QU03,QU08
QU09
QU01,QU06
QU07

PU54


QU51 QU52
QU51
QU52
FR-70 ONLY
FR-60 ONLY
FR-70
ONLY
QU51
QU52



P904





F901 : 3A 125V FR-50
4A 125V FR-60 } (U) VERSION
5A 125V FR-70
T1.0A 250V SR-50L
T1.25A 250V SR-60L } (A,T,W) VERSION

PG04



MARA-00479 / Druck:6



NOTE ON SAFETY:
Symbol ▲ Fire or electrical shock ha
be used to replace any part marked wi
ponent substitution (other than origina
or electrical shock hazard.



NOTE ON SAFETY:
Symbol ⚠ Fire or electrical shock hazard. Only original parts should be used to replace any part marked with symbol ⚠ . Any other component substitution (other than original type), may increase risk of fire or electrical shock hazard.



MARA-00479 / Druck:9

3. EXPLODED VIEW AND PARTS LIST



REF. DESIG.	PART NO.	DESCRIPTION
001B	4822 426 51418	Front Panel Assembly, Up (SR60L)
	4822 426 51421	Front Panel Assembly, Up (SR50L)
005B	4822 426 51416	Front Panel, Down
010B	4822 426 51415	Chassis Assembly, Front
020B	4822 450 61563	Window, Left
021B	4822 450 61566	Window, Right
022B	4822 413 41544	Knob, Volume
023B	4822 410 60343	Button
024B	4822 413 41523	Knob, Bal./Bass/Treble
025B	4822 410 60194	Button, Power
032B	4822 256 91642	Holder, FL
033B	4822 459 10942	Sticker, FL Adhesive
051B	4822 459 80343	Clamper
002D	4822 501 11008	B.T. Screw (W/W) B4 x 8
007G	4822 462 41477	Leg
024G	4822 276 12497	Link, Power Switch
930G	4822 532 60948	Bushing, AC Cord
J031	4822 290 40297	Terminal, GND
▲L001	4822 146 21531	Power Transformer (SR60L)
	4822 146 21529	Power Transformer (SR50L)
001T	4822 736 20652	User Manual (SR60L)
	4822 736 20653	User Manual (SR50L)
Z005	4822 218 10351	Remote Control, RC-60SR

4. TEST EQUIPMENT REQUIRED FOR SERVICING

This table lists the test equipment required for servicing.

Item	Use
Distortion Analyzer	Distortion measurements
Audio Oscillator	Sinewave and squarewave signal source
ACVTVM	Voltage measurements (AC)
Oscilloscope	Waveform analysis and trouble shooting and ASO aignment
Circuit Tester	Trouble shooting
DCVTVM	Voltage measurements (DC)
AC Wattmeter	Monitors primary power to amplifier
Line Voltmeter	Monitors potential of primary power to amplifier
Variable Autotransformer	Adjust level of primery power to amplifier
Shorting Plug	Shorts amplifier input to eliminate noise pickup

5. IDLING CURRENT ADJUSTMENT

(1) Before switching the power ON, set the Master Volume control to the minimum position and the Balance and Tone controls to the center positions. Then, rotate the semi-fixed resistors R719 (L CH) and R720 (R CH) on the PC board PV04 fully clockwise.
(2) Connect a digital voltmeter, set for the DC voltage input to the pertinent test points (the marked ones of R737-R738) on the PC board PV04. (Positive: Rear side, Negative: Front side)
(3) After the completion of the above setup.
Switch the power ON and adjust the semi-fixed resistors R719 (L CH) and R720 (R CH) on the PC board PV04 according to the reading of the digital voltmeter. The setting values are 6 ~ 7.6 mV (16.7 ~ 20 mA) of the both channels.

Please refer to the table below.

Power ON

20 sec later	2mV
1 min later	4mV
More than 5min	6~7.6mV

Measurement point



R737/R738

6. VOLTAGE CONVERSION

● **EUROPEAN MODEL ONLY**
To convert the unit to a different power source voltage, change the position as illustrated in the drawing below.

VOLTAGE SELECTOR



CAUTION
DISCONNECT POWER SUPPLY CORD FROM AC OUTLET BEFORE CONVERTING VOLTAGE.

7. HOW TO CHANGE THE SUPPLY VOLTAGE (T.W. Versions)

Refer to the following diagram for the voltage change procedure.



8. SERVICE PROGRAM

1. T.R POINT ME (tracking point memory) mode.
From power OFF (backup mode), when the power switch is pressed ON while pressing the up and MEMO key simultaneously, the T.R POINT ME mode is called.
Frequencies to be memorized are as follows.

	P1	P2	P3	P4	P5	P6	P7	P8
FM	90.0 MHz	98.0 MHz	106.0 MHz	87.5 MHz				
AM (with LW)					603 kHz	999 kHz	1404 kHz	173 kHz
AM (without LW)					603 kHz	999 kHz	1404 kHz	531 kHz
AM (USA)					600 kHz	1000 kHz	1400 kHz	520 kHz

	P9	P10	P11	P12-P30	
FM					
AM (with LW)	209 kHz	272 kHz	152 kHz	531 kHz	
AM (without LW)	531 kHz	531 kHz	531 kHz	531 kHz	
AM (USA)	520 kHz	520 kHz	520 kHz	520 kHz	

2. Microprocessor and FL operation check program mode
2-1 FL segment check
- This program is to check each FL segment for its lighting.
  (1) When the test mode is entered, microprocessor's MUTE OUT becomes "HIGH" to apply muting to the unit itself. No change occurs in any other setting.
  (2) At first, every segment is aliget. for 3 seconds.

2-2 Service mode (input selector check)
- This program is to check the input selector, etc. of the unit itself for functioning.
  (1) Microprocessor's MUTE OUT is made "LOW".
  (2) In a procedure shown in the following, each object is subject to execution of check for 3 seconds, and operation shifts to the next one. Then, operation starts at step 1.
  (3) At the time of object change, muting is applied at the aforesaid timing.
  (4) When the final step is executed, operation returns to step 1 to repeat.
  (5) When the (UP) key is pressed, operation shifts to the next step. However, in this case, any continuous pressure of this key is not accepted. Operation is stopped by the (D/CL) key and is resumed by the (UP) key. Either is always accepted.

Step	Function	Notes
1	FM	FM mode: Auto, last frequency (initial)
2	FM	FM mode: Mono, last frequency (initial)
3	PHONO	
4	CD	
5	TAPE	
6	TV	
7	CDV	
8	VCR	

9. TUNER ALIGNMENT PROCEDURES

1. When you adjust a set, use a signal generator with a counter with which you can correctly read frequencies, or connect a counter to a signal generator with a counter terminal for both AM and FM.
2. As a rule, use a band-pass filter (B.P.F 200-15 kHz) designated by IHF in adjustment and measurement of FM.
   Be sure to use a filter especially in adjustment of STEREO DISTORTION and SEPARATION. (Attenuation at 19 kHz is to be 30 dB at least.)
3. The controller (QU02) used in this set has a function to preset and memorize the frequencies of guard and tracking point to be used in adjustment and measurement.

   Caution:
   Alignment of FM needs to set the IF BAND SWITCH to "WIDE" position if any other instruction does not require.

4. Adjustment of FM MPX VCO
The part to be adjusted: R314
1) Set the frequency and output of the signal generator at 98 MHz and 500 μV (54 dB)/75 ohms respectively and synchronize the set to them.
2) After confirming that the "TUNED" indicator in FL display is not turned off when you set FM MODE SWITCH in AUTO STEREO position (AUTO is alight), turn off the modulation of the signal generator.
3) After connecting a frequency counter to the test point, UP15, adjust R314 so that the frequency counter shows 228 (±0.05) kHz.



- Set to T.R point ME mode of the service program, after that, needs POWER OFF and POWER ON again. (P1) to (P7) in the Digital Readout Frequency Setting column shows preset numbers for the above mode. Before alignment, connect a dummy resistor of 47 kohms to the tape out terminal.

5. FM Alignment Procedures
(Function switch at "FM" position and MODE switch at "MONAURAL" position)

- **FM RF Alignment**

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	FM signal generator to FM antenna terminal. Adjust the RF signal output so that slight noise occurs at the upper and lower sides of the output waveform.	98.0 MHz	AC VTVM to L- or R-channel output (TAPE OUT)	98.0 MHz (P2)	Front end IFT for maximum output and minimum distortion.
2	FM signal generator 500 μV output to FM antenna terminal (75-ohm).	98.0 MHz		98.0 MHz (P2)	
3			Distortion meter to L- or R-channel output (TAPE OUT)		L201 core for minimum distortion.

- **FM IF Alignment**
(Function switch at "FM" position and MODE switch at "AUTO STEREO" position)

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	FM signal generator 500 μV output modulated by MPX signal generator to FM antenna terminal (75-ohm). Modulation level: IHF 67.5 kHz +9% pilot dev. DIN 40 kHz +8% pilot dev.	Stereo L-channel (1,000 Hz)	VTVM to L-channel output (TAPE OUT L channel)	98.0 MHz (P2)	Front end IFT for minimum distortion.
2		Stereo R-channel (1,000 Hz)	VTVM to R-channel output (TAPE OUT R channel)		

- **Muting Level Alignment**
(Function switch at "FM" position and MODE switch at "AUTO STEREO" position)

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	FM signal generator 6.3 μV output to FM antenna terminal (75-ohm)	98.0 MHz		98.0 MHz (P2)	R211 to a point at which shows "tuned."

- **Multiplex Alignment**
  (Function switch at "FM" position and MODE switch at "AUTO STEREO" position)

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	FM signal generator 500 μV output modulated by MPX signal generator to FM antenna terminal (75-ohm) Modulation level: IHF67.5 kHz +9% pilot dev. DIN 40 kHz +8% pilot dev.	Stereo L-channel (1,000 Hz)	VTVM to R-channel output (TAPE OUT R channel)	98.0 MHz (P2)	R301 so that channel separation is identical between both channels.
2		Stereo R-channel (1,000 Hz)	VTVM to L-channel output (TAPE OUT L channel)		
3	Repeat steps 1 and 2.				

6. AM/MW Alignment Procedures
(Function switch at "AM" position)

- **AM IF Alignment**

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	Sweep generator to AM antenna terminal	450 kHz	AC VTVM to L- or R-channel output (TAPE OUT)	–	FA01 for Europe versions, LA06 Europe USA, versions maximum and symmetrical waveform.

- **AM RF Alignment**

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	AM signal generator to AM loop antenna in a test loop	603 kHz	VTVM to L- or R-channel output (TAPE OUT)	603 kHz (P5)	LA01 for maximum output.
2		1,404 kHz		1,404 kHz (P7)	CA01 for maximum output.
3	Repeat steps 1 and 2 until sensitivity is maximized.				

- **LW RF Alignment**
  (For Europe version)

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	AM signal generator to AM loop antenna in a test loop	173 kHz	VTVM to L- or R-channel output (TAPE OUT)	173 kHz (P8)	LA03 for maximum output.
2		272 kHz		272 kHz (P10)	CA08 for maximum output.
3	Repeat steps 1 and 2 until sensitivity is maximized.				

- **AM Auto Stop Alignment**
  (Function switch at "AM" position)

Step	Signal Source Connection	Signal Frequency	Indicator Connection	Digital Readout Frequency Setting	Adjust
1	RF generator to AM loop antenna in a test loop (500 μV/m)	999 kHz	–	999 kHz (P6)	RA13 so that shows "TUNED" on the display tube lights.

10. ALIGNMENT POINTS AND TEST POINTS



11. TUNER MICROPROCESSOR SPECIFICATIONS

1. Receiving Frequency Range, Channel Space, Reference
Frequency and Intermediate Frequency

		Receiving Frequency	Channel Space	Reference Frequency	Intermediate Frequency
Japan	FM	76.0~90 MHz	100 kHz	25 kHz	−10.7 MHz
	AM	531~1602 kHz	9 kHz	9 kHz	+450 kHz
U.S.A.	FM	87.5~108.0 MHz	100 kHz	25 kHz	+10.7 MHz
	AM	520~1710 kHz	10 kHz	10 kHz	+450 kHz
Europe	FM	87.50~108.00 MHz	50 kHz	25 kHz	+10.7 MHz
	MW	531~1602 kHz	9 kHz	9 kHz	+450 kHz
	LW	152~282 kHz	1 kHz	1 kHz	+450 kHz

Key Matrix



(For initial settings)



MODEL:
A: FR-60/SR-60/60L
B: FR-70
C: FR-50/SR-50/50L

2. Diode switches (for initial settings)

1) U/E JPN : Band setting or selection between USA, Europe and Japan
U/E : 1 (ON setting) for Europe band
0 (OFF setting) for USA band
JPN : 1 for Japan band

2) LW : Band setting for models with LW
When this switch is set to "1", the Europe model is engaged unconditionally, thus having LW.
(Independent of the U/E switch occurring at the above item 1))

3) A/B C : This microprocessor is compatible with 3 models.
When A/B is set to "1", model B is engaged.
When C is set to "1", model C is engaged.
When either is set to "0", model A is engaged.

3. Description of keys

1) 1 ~ 0/CL : Numeral keys for preset memory, which are used in memorizing or calling for preset memory of the tuner. The 0/CL key is also used in stopping of preset scan as well as clearing of preset memory.

2) PRE SET : This key provides the preset scan mode. When this key is pressed, "PRESET SCAN" flickers at 0.5 cycle/sec on the FL display. Thus, within 5 seconds, when the UP or DN key is pressed, preset scan is started and "PRESET SCAN" flickers at 1 cycle/sec on the FL display.

3) F/P : This switch selects an FL display mode between the frequency display and the preset No. display.

4) ME : This key is used in writing or clearing the preset memory.
*The ME key is enabled for 5 seconds, during which period when no preset No. is input, operation returns to the just previous status.
*Auto memory operation
Scan is automatically applied to within the band, and any receivable stations are stored in preset memory in a successive manner. This feature is enabled due to the simultaneous pressures of the ME key and the UP or DN key.

5) 0/CL : A numeral key. Besides, clearance of preset memory, stop of preset scan, stop of auto memory, etc.

6) FM : Pressed for FM reception

7) AM : Pressed for AM reception
For a model with LW, this key selects between MW and LW in a cyclic manner. "MW" or "LW" appears on the FL display.

8) DN , UP : Frequency up/down for frequency mode, and preset channel up/down for preset mode

9) PH , CD , TAPE , TV , CDV , VCR :
Each selects its corresponding function as the input.

10) WAKE UP : When the power is turned ON, a preprogrammed mode is output using a code of RC-5 to operate another connected unit.

11) FM MODE : Selection between auto stereo and mono at FM

Pin Connections (TMP47C870N)



Port Name		Pin No.	I/O	Act	Function
VKK	–	1	–	–	-33V
S0	Sa	2	O	H	FL Segment output
S1	Sb	3	O	H	
S2	Sc	4	O	H	
S3	Sd	5	O	H	
S4	Se	6	O	H	
S5	Sf	7	O	H	
S6	Sg	8	O	H	
S7	Sh	9	O	H	
S8	Si	10	O	H	
S9	Sj	11	O	H	
S10	Sk	12	O	H	
R53	P13	13	O	H	FOR STANDBY AND RC. RECEIVED LED
K00	K1	14	I	H	KEY MATRIX input
K01	K2	15	I	H	
K02	K3	16	I	H	
K03	K4	17	I	H	
TEST	–	18	–	–	GND
XIN	–	19	I	–	For Oscillation element (4.19 MHz)
XOUT	–	20	O	–	
$\overline{RESET}$	–	21	I	L	Watch dog timer input or reset terminal
$\overline{HOLD}$	–	22	I	L	POWER DOWN DETECTOR INPUT
P00	P11	23	O	H	POWER, L: STANDBY
R60	K5	24	I	H	KEY MATRIX INPUT
R61	K6	25	I	H	KEY MATRIX INPUT
R62	A1	26	O	H	KEY MATRIX output
R63	A2	27	O	H	
R64	A3	28	O	H	
R65	A4	29	O	H	
R66	A5	30	O	H	
R67	A6	31	O	H	
VSS	–	32	–	–	GND

Port Name		Pin No.	I/O	Act	Function
P20	P1	33	O	H	Control signal output, H: TV
P21	P2	34	O	H	Control signal output, H: CDV
P22	P3	35	O	H	TAPE MONITOR LED DRIVE
P23	P4	36	O	H	MONO/STEREO, L: MONO
R70	P5	37	O	H	Control signal output, H: TUNER
$\overline{WTO}$	–	38	O	L	WATCH DOG TIMER OUTPUT
R72	P6	39	O	H	Muting output
R73	CE	40	O	H	Chip selector for PLL IC LM7000N
R80	RC-5	41	I	L	Remote control signal input
R81	$\overline{ST}$	42	I	L	AUTO SCAN STOP signal input
R82	STRQ	43	O	H	STATION REQUEST TERMINAL
R83	$\overline{SD}$	44	I	L	STATION DETECTOR
R90	CE	45	O	H	Chip selector for Audio selector LC7821
SO	DO	46	O	H	Data output
$\overline{SCK}$	CLK	47	O	H	Clock output
R30	P7	48	O	H	STEREO IND., H: STEREO
R31	P8	49	O	H	VOLUME DOWN
R32	P9	50	O	H	VOLUME UP
R33	P10	51	O	H	CATV CONTROL, H: RELAY ON
RA0	P12	52	I	H	SPK RELAY
RA1	RC-5	53	O	H	Serial output for Wake up mode
G9	D10	54	O	H	FL digit drive output
G8	D9	55	O	H	
G7	D8	56	O	H	
G6	D7	57	O	H	
G5	D6	58	O	H	
G4	D5	59	O	H	
G3	D4	60	O	H	
G2	D3	61	O	H	
G1	D2	62	O	H	
G0	D1	63	O	H	
VDD	–	64	–	–	+5V

12. ELECTRICAL PARTS LIST

ASSIGNMENT OF COMMON PARTS CODES.

RESISTOR

R***: (1) GD05---140, Carbon film fixed resistor, ±5%, 1/4W
R***: (2) GD05---160, Carbon film fixed resistor, ±5%, 1/6W
① — Resistance value

Examples
① Resistance value

0.1Ω...001	10Ω...100	1kΩ...102	100kΩ...104
0.5Ω...005	18Ω...180	2.7kΩ...272	680kΩ...684
1Ω...010	100Ω...101	10kΩ...103	1MΩ...105
6.8Ω...068	390Ω...391	22kΩ...223	4.7MΩ...475

(Note) Please distinguish 1/4W from 1/6W by the shape of parts used actually.

C***: CERAMIC CAP.
(1) DD1---370, Ceramic condenser
①② Disc type
Temp. coeff. P350 ~ N1000, 50V
② — Capacity value
① — Tolerance

Examples
① Tolerance (Capacity deviation)
±0.25pF...0
±0.5pF...1
±5%...5
* Tolerance of COMMON PARTS handled here are as follows:
0.5pF ~ 5pF...±0.25pF
6pF ~ 10pF...±0.5pF
12pF ~ 560pF...±5%
② Capacity value

0.5pF...005	3pF...030	100pF...101
1pF...010	10pF...100	220pF...221
1.5pF...015	47pF...470	560pF...561

C***: CERAMIC CAP.
(1) DK16---300, High dielectric constant ceramic condenser
① Disc type
Temp. chara. 2B4, 50V
② — Capacity value

Example
② Capacity value

100pF...101	1000pF...102	10000pF...103
470pF...471	2200pF...222	

C***: ELECTROLY CAP. (⇄), FILM CAP. (⇌)
(1) EA------10, Electrolytic condenser
①② One-way lead type, Tolerance ±20%
② — Dielectric strength
① — Capacity value

Examples
① Capacity value

0.1μF...104	4.7μF...475	100μF...107
0.33μF...334	10μF...106	330μF...337
1μF...105	22μF...226	1100μF...108
		2200μF...228

② Working voltage

6.3V...006	25V...025
10V...010	35V...035
16V...016	50V...050

(2) DF15---350, Plastic film condenser
① One-way type, Mylar ±5% 50V
① — Capacity value

Examples
① Capacity value

0.001μF (1000pF)...102	0.1μF...104
0.0018μF.....182	0.56μF...564
0.01μF.....103	1μF...105
0.015μF.....153	

REF. DESIG.	PART NO.	DESCRIPTION
		PG04-MASTER VOLUME CIRCUIT BOARD
CG01	4822 122 32486	Ceramic Cap. 0.01μF +80% −20%
RG01	4822 100 30127	Variable Resistor 100KΩ(D)x2
		PT04-HEADPHONE/SPEAKER SW. CIRCUIT BOARD
RT01	4822 116 60262	Resistor 330Ω ±5% 2W (SR60L)
	4822 111 50474	Resistors 330Ω ±5% 1W (SR50L)
RT02	4822 116 60262	Resistor 330Ω ±5% 2W (SR60L)
	4822 111 50474	Resistors 330Ω ±5% 1W (SR50L)
JT01	4822 267 31126	Jack, Headphone
ST01	4822 276 20504	Push Switch, Speaker
		PU04-U-COM/TACT SW./FL CIRCUIT BOARD
CU04	4822 122 40586	Ceramic Cap. 0.01μF ±20%
CU05	4822 124 23128	Elect Cap. 0.047μF 5.5V
GU01	4822 111 91936	Resistor, Array 10KΩx14
GU02	4822 111 91678	Resistor, Array 10KΩx7
GU05		Capacitor, Array 470pF/100KΩx4
DU01 ~ DU04	4822 130 33305	Diode 1SS176, etc.
DU06 ~ DU08	4822 130 33305	Diode 1SS176, etc.
DU10	4822 130 33305	Diode 1SS176, etc.
DU14	4822 130 33305	Diode 1SS176, etc.
DU15	4822 130 33305	Diode 1SS176, etc.
DU17	4822 130 80325	L.E.D. LT3H8B (YEL)
DU18	4822 130 80326	L.E.D. LT3D8B (RED)
DU24	4822 130 33305	Diode 1SS176, etc. (SR50L)
DU25	4822 130 33305	Diode 1SS176, etc. (SR50L)
DU26	4822 130 33305	Diode 1SS176, etc.
DU27	4822 130 33305	Diode 1SS176, etc.
QU01	4822 130 42682	Transistor, Digital DTA144ES
QU02	4822 209 62558	Microprocessor TMP47C870N
QU03	4822 130 42594	Transistor, Digital DTC144ES
QU04	4822 209 82139	Photo Unit PAS-C0617
QU05	4822 130 42298	Transistor 2SC536SP, etc.
QU06	4822 130 42682	Transistor, Digital DTA144ES
QU07	4822 130 42682	Transistor, Digital DTA144ES
QU08	4822 130 42594	Transistor, Digital DTC144ES
QU09	4822 130 42594	Transistor, Digital DTC144ES
SU01 ~ SU06	4822 276 12455	Push Switch, Tact
SU08 ~ SU10	4822 276 12455	Push Switch, Tact
SU12 ~ SU27	4822 276 12455	Push Switch, Tact

REF. DESIG.	PART NO.	DESCRIPTION
VU01	4822 130 90857	Display Unit FIP10BGM8
XU01	4822 242 72194	Ceramic Viblator 4.19MHz
		PU54-CONNECTOR CIRCUIT BOARD
DU51	4822 130 33305	Diode 1SS176, etc.
QU51	4822 130 42594	Transistor, Digital DTC144ES
QU52	4822 130 42682	Transistor, Digital DTA144ES
		PV04-FUNCTION/MAIN AMP/ VIDEO CIRCUIT BOARD
		PV04-CAPACITORS
CL08	4822 122 32486	Ceramic 0.01μF +80% −20% (SR60L)
CL10	4822 122 32486	Ceramic 0.01μF +80% −20% (SR60L)
CN05	4822 122 32486	Ceramic 0.01μF +80% −20%
CV01 ~ CV06	4822 122 32486	Ceramic 0.01μF +80% −20%
CV09 ~ CV11	4822 122 32486	Ceramic 0.01μF +80% −20%
C419	4822 122 32486	Ceramic 0.01μF +80% −20%
C705	4822 122 32917	Ceramic 33pF ±5%
C706	4822 122 32917	Ceramic 33pF ±5%
C711	4822 126 10797	Ceramic 10pF ±0.5pF
C712	4822 126 10797	Ceramic 10pF ±0.5pF
C713	4822 122 40367	Ceramic 7pF ±0.5pF
C714	4822 122 40367	Ceramic 7pF ±0.5pF
C717	4822 122 32895	Ceramic 100pF ±5%
C718	4822 122 32895	Ceramic 100pF ±5%
C719	4822 122 32895	Ceramic 100pF ±5%
C720	4822 122 32895	Ceramic 100pF ±5%
C727		Elect 100μF 63V (SR60L)
C728		Elect 100μF 63V (SR60L)
C729	4822 122 32486	Ceramic 0.01μF +80% −20%
C801	4822 122 32486	Ceramic 0.01μF +80% −20%
C802	4822 122 32486	Ceramic 0.01μF +80% −20%
C811	4822 122 30043	Ceramic 0.01μF +80% −20%
▲C812		Elect 8200μF 56V (SR60L)
	4822 124 41603	Elect 4700μF 50V (SR50L)
▲C813		Elect 8200μF 56V (SR60L)
	4822 124 41603	Elect 4700μF 50V (SR50L)
		PV04-RESISTORS
RE19	4822 100 30126	10KΩ(C), Variable
RE20	4822 100 30126	10KΩ(C), Variable
▲RN19	4822 116 60332	1KΩ ±5% 2W (SR60L)
	4822 116 60272	820Ω ±5% 2W (SR50L)
RV31	4822 100 30125	100KΩ(W), Variable

REF. DESIG.	PART NO.	DESCRIPTION
▲R417	4822 116 52892	100Ω ±5% ¼W
▲R418	4822 116 52892	100Ω ±5% ¼W
R713		68Ω ±5% 1/6W
R714		68Ω ±5% 1/6W
R719	4822 100 11386	1KΩ, Trimming
R720	4822 100 11386	1KΩ, Trimming
R725 ~ R730		68Ω ±5% 1/6W
▲R731	4822 116 60246	220Ω ±5% 1W
▲R732	4822 116 60246	220Ω ±5% 1W
R733 ~ R736	4822 111 91291	10Ω ±5% 1/6W
▲R737	4822 116 82049	0.18Ωx2 ±10% 3W
▲R738	4822 116 82049	0.18Ωx2 ±10% 3W
R739		68Ω ±5% 1/6W
R740		68Ω ±5% 1/6W
R743	4822 111 90726	10Ω ±5% 2W
R744	4822 111 90726	10Ω ±5% 2W
▲R745	4822 116 82523	4.7KΩ ±5% 1W
R801	4822 116 82524	27Ω ±5% ½W, Fusible (SR50L)
▲R803	4822 116 60331	1KΩ ±5% 1W
▲R804	4822 116 82525	390Ω ±5% ½W, Fusible (SR60L)
	4822 116 81316	470Ω ±5% ¼W, Fusible (SR50L)
▲R807	4822 116 60306	1Ω ±5% ½W, Fusible (SR60L)
	4822 116 60307	1Ω ±5% ¼W, Fusible (SR50L)
▲R810	4822 116 60306	1Ω ±5% ½W, Fusible (SR60L)
	4822 116 60307	1Ω ±5% ¼W, Fusible (SR50L)
		PV04-SEMICONDUCTORS
DL01	4822 130 33305	Diode 1SS176, etc. (SR60L)
DL02	4822 130 33305	Diode 1SS176, etc. (SR60L)
DL03	4822 130 33305	Diode 1SS176, etc. (SR60L)
DN01	4822 130 80837	Diode HSS81TD
DN02	4822 130 80837	Diode HSS81TD
DN03	4822 130 33305	Diode 1SS176, etc.
D701	4822 130 80273	Zener RD8.2JB2/MTZJ8.2C
D702	4822 130 80322	Zener RD15JB3/MTZJ15A
D703 ~ D706	4822 130 33305	Diode 1SS176, etc.
▲D801	4822 130 80839	Diode S5688G
▲D803	4822 130 80839	Diode S5688G
▲D805	4822 130 80839	Diode S5688G
▲D807	4822 130 80839	Diode S5688G
▲D808	4822 130 80839	Diode S5688G
▲D809	4822 130 80839	Diode S5688G
▲D810	4822 130 81287	Zener RD33FB2
▲D811	4822 130 80319	Zener RD9.1JB2/MTZJ9.1C
▲D812	4822 130 81093	Diode BR82
D813	4822 130 33305	Diode 1SS176, etc.
D815	4822 130 80839	Diode S5688G
D816	4822 130 80839	Diode S5688G
D817	4822 130 80091	Zener RD12JB2/MTZJ12C

REF. DESIG.	PART NO.	DESCRIPTION
QE01	4822 130 42298	Transistor 2SC536SP, etc.
QE02	4822 130 42298	Transistor 2SC536SP, etc.
QE03	4822 209 73064	IC NJM2068DD
QL01	4822 209 73275	IC TC9214F (SR60L)
QL02	4822 130 42298	Transistor 2SC536SP, etc. (SR60L)
QL03	4822 130 42298	Transistor 2SC536SP, etc. (SR60L)
QL04	4822 130 42594	Transistor, Digital DTC144ES (SR60L)
QN01	4822 130 43223	Transistor 2SC2240(GR, BL)
QN02	4822 130 43233	Transistor 2SC2240(GR, BL)
QN03	4822 130 42951	Transistor 2SA970(GR, BL)
QN04	4822 209 83312	IC TA7317P
QV01	4822 209 72748	IC LC7821
QV02	4822 209 73275	IC TC9214P
QV03	4822 209 73287	IC LB1630
Q401	4822 209 83631	IC NJM4558DD
Q701	4822 130 42951	Transistor 2SA970(GR, BL)
Q702	4822 130 42951	Transistor 2SA970(GR, BL)
Q703	4822 130 43233	Transistor 2SC2240(GR, BL)
Q704	4822 130 43233	Transistor 2SC2240(GR, BL)
Q705	4822 130 60117	Transistor 2SC3419(Y)
Q706	4822 130 60117	Transistor 2SC3419(Y)
▲Q707	4822 130 62335	Transistor 2SD2033(E)
▲Q708	4822 130 62335	Transistor 2SD2033(E)
▲Q709	4822 130 62334	Transistor 2SB1353(E)
▲Q710	4822 130 62334	Transistor 2SB1353(E)
▲Q711	4822 130 61747	Transistor 2SC3182(R, O) (SR60L)
	4822 130 60697	Transistor 2SC3180(R, O) (SR50L)
▲Q712	4822 130 61747	Transistor 2SC3182(R, O) (SR60L)
	4822 130 60697	Transistor 2SC3180(R, O) (SR50L)
▲Q713	4822 130 61746	Transistor 2SA1265(R, O) (SR60L)
	4822 130 60694	Transistor 2SA1263N(R, O) (SR50L)
▲Q714	4822 130 61746	Transistor 2SA1265(R, O) (SR60L)
	4822 130 60694	Transistor 2SA1263N(R, O) (SR50L)
Q715	4822 130 42298	Transistor 2SC536SP, etc.
Q716	4822 130 42298	Transistor 2SC536SP, etc.
Q717	4822 209 83732	IC AN7062P
Q718	4822 130 42594	Transistor, Digital DTC144ES
Q719	4822 130 42682	Transistor, Digital DTA144ES
▲Q801	4822 209 60826	IC NJM7812FA
▲Q802	4822 209 61533	IC NJM7806FA
Q804	4822 130 42298	Transistor 2SC536SP, etc.
Q805	4822 130 42298	Transistor 2SC536SP, etc.
Q806	4822 130 42682	Transistor, Digital DTA144ES
		PV04-MISCELLANEOUS
JL01	4822 265 30627	Terminal, 3P RCA (SR60L)
JL02	4822 267 31208	Terminal, 2P RCA (SR60L)
JV01	4822 265 30397	Terminal, 4P RCA
JV02	4822 265 30397	Terminal, 4P RCA
JV03	4822 265 30457	Terminal, 6P RCA
JV04	4822 266 30274	Terminal, 2P RCA
J401	4822 267 30741	Terminal, 2P RCA

REF. DESIG.	PART NO.	DESCRIPTION
LN01	4822 280 70354	Relay
L701	4822 157 51739	Coil, Speaker
L702	4822 157 51739	Coil, Speaker
SE01	4822 276 12926	Push Switch, Bass EQ
		PW04-SPEAKER TERMINAL CIRCUIT BOARD
CW01 ~ CW04	4822 122 32486	Ceramic Cap. 0.01μF +80% −20%
JW01	4822 290 60686	Terminal, Speaker
		P104-FRONT-END/IF BLOCK CIRCUIT BOARD
		P104-CAPACITORS
CA01	4822 125 50384	Trimming 20pF
CA02	4822 122 40491	Ceramic 0.022μF +80% −20%
CA03		Ceramic 15pF ±5%
CA04	4822 122 31205	Ceramic 47pF ±5%
CA05	4822 121 41629	Film 390pF ±5%
CA06	4822 122 32486	Ceramic 0.01μF +80% −20%
CA07	4822 122 32486	Ceramic 0.01μF +80% −20%
CA08	4822 125 50384	Trimming 20pF
CA09		Ceramic 15pF ±5%
CA11	4822 122 40568	Ceramic 68pF ±5%
CA12	4822 122 10367	Ceramic 150pF ±5%
CA13	4822 122 32486	Ceramic 0.01μF +80% −20%
CA14	4822 122 32486	Ceramic 0.01μF +80% −20%
CA15	4822 122 32486	Ceramic 0.01μF +80% −20%
CA16	4822 122 40491	Ceramic 0.022μF +80% −20%
CA19	4822 122 32486	Ceramic 0.01μF +80% −20%
CA20	4822 122 40491	Ceramic 0.022μF +80% −20%
CA22	4822 122 32486	Ceramic 0.01μF +80% −20%
CA24	4822 122 32486	Ceramic 0.01μF +80% −20%
C201	4822 122 40491	Ceramic 0.01μF +80% −20%
C202	4822 122 40491	Ceramic 0.01μF +80% −20%
C203	4822 122 40491	Ceramic 0.022μF +80% −20%
C204	4822 122 40491	Ceramic 0.022μF +80% −20%
C206	4822 122 40491	Ceramic 0.022μF +80% −20%
C211	4822 122 40491	Ceramic 0.022μF +80% −20%
C226	4822 122 40491	Ceramic 0.022μF +80% −20%
C310	4822 121 41623	Film 1000pF ±5%
		P104-RESISTORS
RA13	4822 100 11352	22KΩ, Trimming
▲R210	4822 116 52846	150Ω ±5% ¼W
R211	4822 100 11471	100KΩ, Trimming
R301	4822 100 11351	10KΩ, Trimming
		P104-SEMICONDUCTORS
DA01	4822 125 50416	Varicap SVC342
DA02	4822 130 33305	Diode 1SS176, etc.
DA03	4822 125 50416	Varicap SVC342
DA04	4822 130 33305	Diode 1SS176, etc.
QA01	4822 130 42298	Transistor 2SC536SP, etc.
QA02	4822 130 42298	Transistor 2SC536SP, etc.
QA03	4822 130 42298	Transistor 2SC536SP, etc.

REF. DESIG.	PART NO.	DESCRIPTION
Q201	4822 209 71785	IC LA1266
Q202	4822 130 42082	Transistor 2SC1047(C)
		P104-MISCELLANEOUS
A101	4822 210 10372	V.H.F. Tuner, FE415-G09
FA01	4822 242 71509	Ceramic Filter
F201	4822 242 71135	Ceramic Filter, SFE10.7MS3-A
F202	4822 242 71135	Ceramic Filter, SFE10.7MS3-A
J101	4822 266 30298	Terminal, Antenna
LA01	4822 157 52328	Ant Coil, MW
LA02	4822 157 52716	OSC Coil, MW
LA03	4822 157 52714	Ant Coil, LW
LA04	4822 157 52717	OSC Coil, LW
LA05	4822 157 53589	Choke Coil, 39mH
L201	4822 148 81096	I.F.T. Coil, FM DET
		P304-MPX/PLL BLOCK CIRCUIT BOARD
		P304-CAPACITORS
CA15	4822 122 32486	Ceramic 0.01μF +80% −20%
CA21	4822 122 40568	Ceramic 68pF ±5%
C210	4822 122 40568	Ceramic 68pF ±5%
C310	4822 121 41623	Film 1000pF ±5%
C501	4822 122 31205	Ceramic 47pF ±5%
C502	4822 122 31205	Ceramic 47pF ±5%
C504	4822 122 32486	Ceramic 0.01μF +80% −20%
C507	4822 122 32486	Ceramic 0.01μF +80% −20%
C508	4822 122 32486	Ceramic 0.01μF +80% −20%
C509	4822 122 40491	Ceramic 0.022μF +80% −20%
		P304-RESISTORS
▲ R311	4822 116 52849	220Ω ±5% ¼W
R314	4822 100 11351	10KΩ, Trimming
▲ R514	4822 116 52849	220Ω ±5% ¼W
		P304-SEMICONDUCTORS
D301	4822 130 33305	Diode 1SS176, etc.
D501	4822 130 80317	Zener RD5.1JB2/MTZJ5.1B
QA04	4822 130 42682	Transistor, Digital DTA144ES
QA05	4822 130 42682	Transistor, Digital DTA144ES
QA06	4822 130 42682	Transistor, Digital DTA144ES
Q204	4822 130 42682	Transistor, Digital DTA144ES
Q301	4822 209 71776	IC TEA5581
Q501	4822 209 62557	IC LM7000N
Q503	4822 130 42298	Transistor 2SC536SP, etc.
Q504	4822 130 42298	Transistor 2SC536SP, etc.
		P304-MISCELLANEOUS
X501	4822 242 72333	Crystal, 7.2MHz
		P904-POWER SW./B-UP TRANSF. CIRCUIT BOARD
▲ C901	4822 122 33276	Ceramic Cap. 0.01μF ±20%
▲ F901	4822 253 20145	Fuse T1.25A 250V (SR60L)
	4822 253 30201	Fuse 1.0A 250V (SR50L)
▲ S901	4822 276 12924	Push Switch, Power (SR60L)
	4822 276 12925	Push Switch, Power (SR50L)

NOTE ON SAFETY:
Symbol ▲ Fire or electrical shock hazard. Only original parts should be used to replace any part marked with symbol ▲ . Any other component substitution (other than original type), may increase risk of fire or electrical shock hazard.